

High-Rise Procedure Appendix 4

High-Rise Pack

Several committee members have expressed an interest in having a regional high-rise pack/equipment requirement. At the very least, the equipment used by each department should have inter-operability with departments they commonly run with in first and second due areas.

High Rise Pack/High Rise Equipment (Suggested Contents) ******DRAFT******

200' 2 or 2.5" Hose (2.5 inch couplings)

Smoothbore or Break Away Nozzle (15/16, 1, or 1 1/8 inch capability)

Elbow (Some have pressure relief option)

Inline Gate Valve

Inline Flow/Pressure Gauge (can be marked with optimal pressures from outlet)

2.5" to 1.5" Reducers (for inter-operability with units that may have small diameter hose)

Standpipe Wheel

18" Pipe Wrench

HFT/Rabbit Tool (great for forcing multiple inward swinging doors)

Multiple Door Chocks (long ones can also be used as sprinkler wedges)

1 1/16 ratchet (can be used to re-calibrate some PRV's)

Permanent Markers or Grease Pencils (for Division Officers to be used for accountability)

Door Tags/method for marking searched areas

*In House Phones w/ Quarter Inch Jack

LED Flashlight or Cyalume Sticks for Illumination